



NO NEED TO SET ZERO
BEFORE USE

SHORT LEVEL



4907-90

- No need to set zero before use
- Suitable for small spaces like crankshaft
- Longitudinal and transverse V-grooves on bottom for shafts (shafts dia. 19.3~115.9mm)
- With transverse vial

Code	Length	Sensitivity
4907-90	90mm	0.1mm/m(=0.0057°)

