



NO NEED TO SET ZERO
BEFORE USE

MINI LEVEL



4908-100

- No need to set zero before use
- With mounting holes (for M5 screw)

Code	Length	Sensitivity
4908-100	100mm	0.1mm/m($=0.0057^\circ$)

