## **DIGITAL INSIDE GROOVE CALIPERS**



Non waterpro	of, preset (no need to	(mm)										
Code	Range	Туре	Accuracy	L	а	b	С	d	е	f	Data output cable (optional)	
1120-150A	22-150mm/0.87-6"	A	±0.04mm	250	5	11	16	30	1	4		
1120-1501	35-150mm/1.38-6"	Α	±0.06mm	250	6	17.5	16	60	1.5	4		
1120-200A	25-200mm/0.98-8"	А	±0.04mm	310	5	12.5	16	40	1	4	7315-25 (receiver is needed) ,	
1120-2001	40-200mm/1.57-8"	A	±0.06mm	310	7	20	16	70	2.5	4	7302-21	
1120-300A	30-300mm/1.18-12"	A	±0.05mm	410	5	15	16	50	1.5	4		
1120-3001	50-300mm/1.97-12"	A	±0.07mm	410	8	25	16	80	2.5	4		
1120-500	40-500mm/1.57-20"	A	±0.07mm	680	5	20	24	90	2.2	5.5	7315-22 (receiver is needed),	
1120-5001	60-500mm/2.36-20"	A	±0.08mm	680	10	30	24	120	3.4	5.5	<b>7302-22</b> (receiver is needed) ,	
1120-5002	80-500mm/3.15-20"	A	±0.08mm	680	16	40	24	150	5.2	5.5		

Non waterproof, preset (no need to add the width of the jaws on the reading), built-in wireless (receiver code 7315-2/3/6/7/8/9 is needed)

Code	Range	Туре	Accuracy	L	а	b	с	d	е	f
1120-150AWL	22-150mm/0.87-6"	А	±0.04mm	250mm	5mm	11mm	16mm	30mm	1mm	4mm
1120-1501WL	35-150mm/1.38-6"	А	±0.06mm	250mm	6mm	17.5mm	16mm	60mm	1.5mm	4mm
1120-200AWL	25-200mm/0.98-8"	А	±0.04mm	310mm	5mm	12.5mm	16mm	40mm	1mm	4mm
1120-2001WL	40-200mm/1.57-8"	А	±0.06mm	310mm	7mm	20mm	16mm	70mm	2.5mm	4mm
1120-300AWL	30-300mm/1.18-12"	А	±0.05mm	410mm	5mm	15mm	16mm	50mm	1.5mm	4mm
1120-3001WL	50-300mm/1.97-12"	А	±0.07mm	410mm	8mm	25mm	16mm	80mm	2.5mm	4mm
1120-500WL	40-500mm/1.57-20"	А	±0.07mm	680mm	5mm	20mm	24mm	90mm	2.2mm	5.5mm
1120-5001WL	60-500mm/2.36-20"	А	±0.08mm	680mm	10mm	30mm	24mm	120mm	3.4mm	5.5mm
1120-5002WL	80-500mm/3.15-20"	А	±0.08mm	680mm	16mm	40mm	24mm	150mm	5.2mm	5.5mm

## Non waterproof, no preset (need to add the width of the jaws on the reading)

Code	Range	Туре	Accuracy	L	а	b	с	d	е	f
1120-150B	50-150mm/1.97-6"	В	±0.06mm	270mm	8mm	25mm	20mm	90mm	3.4mm	4mm
1120-200B	60-200mm/2.36-8"	В	±0.06mm	320mm	10mm	30mm	20mm	100mm	3.4mm	4mm
1120-300B	60-300mm/2.36-12"	В	±0.07mm	420mm	10mm	30mm	20mm	110mm	3.4mm	4mm

IP67 dust/waterproof, no automatic power off, set zero after power on each time, no preset (need to add the width of the jaws on the reading), without data interface

Code Range Type Accuracy L a b c d e f   1120-150P 22-150mm/0.87-6" C ±0.04mm 250mm 5mm 11mm 16mm 30mm 1mm 4mm	to preset (need to dud the what of the juws of the reduing), which data menade										
<b>1120-150P</b> 22-150mm/0.87-6" C ±0.04mm 250mm 5mm 11mm 16mm 30mm 1mm 4mm	Code	Range	Туре	Accuracy	L	а	b	С	d	е	f
	1120-150P	22-150mm/0.87-6"	С	±0.04mm	250mm	5mm	11mm	16mm	30mm	1mm	4mm